



Each shipment of Saturn™ TLD Rings contains a packing list, rings, a control dosimeter(s) for each dosimeter type and a return envelope or label to be used to return the dosimeters to Landauer’s laboratory for processing.

Landauer ships the Saturn™ Rings in a plastic bag with the Account and Participant information detailed on the bag. A maximum of 10 Saturn™ Rings are included in each bag. Also, the bags are perforated on the right side for easy opening! Use the ring(s) beginning on the wear date or as close to that date as possible.

Controls are included in the bag with the TLD Rings and can be distinguished by the yellow cap and red body. **Control ring dosimeters should not be worn.**

If you were previously receiving the U TLD Ring, all of the ring sizes converted automatically according to the table below:

U TLD Ring	Saturn Ring
S - Size 5	S - Size 5-8
M - Size 8	
L - Size 11	L - Size 9-16
XL - Size 16	

If you would like to make a change to the size of a ring for a participant for the next wear period, you can do so on [myLDR.com](http://myLDR.com) or by calling Customer Service at 800-323-8830.

The size of the Saturn™ Ring is easily adjusted and can be made larger by applying an external twist and can be tightened by applying an external pressure.

### Display Information:



*Subaccount and Account details are not included on the Saturn™ Ring – this information is readily available by going to [myLDR.com](http://myLDR.com) and navigating to the Unreturned Dosimeter Screen (you can search on the ring serial number).*

### Other Features of the Saturn™ Ring:

- Minimum Reportable Dose of 10 mrem
- A 2D barcode enabling it to be scanned into [myLDR.com](http://myLDR.com) before it is returned to LANDAUER
- Available in Blue, Orange and Green – colors are customizable via [myLDR.com](http://myLDR.com) or by contacting Customer Service